



# MEIRI 2657-USB Version 1.7

## USER MANUAL



# TABLE OF CONTENTS

TABLE OF CONTENTS .....	2
SAFETY INSTRUCTIONS .....	3
WARNING.....	3
PRECAUTIONS.....	3
ELECTRICAL WIRINGS .....	3
PRECAUTIONS ON THE LOCATION  .....	3
GROUNDING THE EQUIPMENT  .....	3
OTHER PRECAUTIONS  .....	3
LITHIUM BATTERY.....	3
CLEANING.....	3
WARRANTY .....	3
FRONT AND REAR PANELS OF THE 2657.....	4
SET UP OF THE 2657 .....	5
MENUS OF THE 2657 VERSION 1.1 .....	5
DISPLAY IN MODE « RUN » (AFTER PRESSING THE ESCAPE KEY).....	11
ALARM RELAYS STATES .....	12
CONNECTORS PINOUT (REAR PANEL) .....	14
<i>RS 232C connector pin out</i> .....	14
<i>DB15 male Connector</i> .....	14
INPUT/OUTPUT EQUIVALENT SCHEMATICS .....	15
<i>ANALOGUE OUTPUTS</i> .....	15
<i>RESET, PRINT, TARA Inputs</i> .....	15
<i>Relays contacts</i> .....	15
SENSOR B            SENSOR A.....	16
PC 2657 SOFTWARE INSTALLATION GUIDE .....	17
“2657” SOFTWARE LAYOUT .....	18
SIGNAL CONDITIONER CONFIGURATION .....	19
VIEWING REAL-TIME WAVEFORMS.....	21
DATA ACQUISITION ON THE PC .....	22
DATA ACQUISITION ON THE PC .....	22
<i>Data acquisition files</i> .....	23
TECHNICAL CHARACTERISTICS .....	24
END OF DOCUMENT .....	27

## Safety Instructions

### PLEASE READ THIS MANUAL BEFORE PROCEEDING ANY HANDLING

#### WARNING

Keep this manual in a safe place for further usage.

#### PRECAUTIONS

Always follow the basic precautions listed below to avoid accidents such as electric shock, short circuit, fire and other damage. These precautions given below are not exhaustive.

#### ELECTRICAL WIRINGS

Only use the approved power source. This information is located on the nameplate of the manufacturer. Be sure that the mains voltage is the same as the one written on the rear of the device. The electric line must contain a switch with two poles. The equipment must be able to easily disconnect. The device must be installed so that the mains plug remains accessible.

The manufacturer declines all responsibilities in case of improper use of the device. Periodically check the state of the plug. Only use the included power cord. Do not leave the power cord near heat sources as radiators or heating installations. Avoid overbending the cable, damaging it or placing it under heavy objects. Never open the device, do not remove or modify internal parts. The user can only remove or insert cards on the front, no intervention on internal parts of the device is required. If the measuring instrument is malfunctioning, turn off the power immediately and give it to a MEIRI qualified technician for inspection.

#### PRECAUTIONS ON THE LOCATION

Using this measuring device in the following locations can lead to a malfunction: right under the sun, hot or very humid places, dusty or dirty areas, places subjected to strong vibrations or near magnetic fields. Avoid leaving the device in the rain or damp places. Do not place liquid containers on it. Never touch an electric plug with wet hands. If the power cord is damaged or if you detect unusual smell or smoke, immediately turn off the switch, remove the plug from the outlet, and give the measuring device to a MEIRI qualified technician for revision.

#### GROUNDING THE EQUIPMENT

Always connect the three-pole plug to a properly grounded power supply. The electrical safety of this equipment is only assured if it is properly connected to an installation of grounding standards for electrical safety. It is essential to check whether this basic requirement of security is met. During installation, there should be a two-pole switch with at least 3 mm contact opening.

#### OTHER PRECAUTIONS

Disconnect all connected cables before moving the measuring device. Do not disassemble this device without removing all the cables from the rear panel, including the power cord. The disassembly by a person not authorized by MEIRI would cancel the warranty. Do not place the objects in front of the air vents of the measurement unit that would prevent adequate ventilation of the internal components and cause overheating. Before connecting the measuring device to other electronic components, turn off the power. Do not insert objects in paper, metal or other into the cover's slot. If this happens, immediately turn off and unplug the power cord from the mains and have the instrument inspected by a qualified person. Do not use excessive force on the buttons, switches and connectors.

#### LITHIUM BATTERY

The measuring device has a lithium battery (CR1220BE) and calendar data (date and time) are kept even if you unplug the device. However, if the battery is completely discharged, date and time would be lost. However, the accuracy of the measurements would not be affected. Don't throw away the flat batteries, bring them to appropriate collection places.

#### CLEANING

Before any cleaning or maintenance, disconnect the unit by disconnecting the plug or turning off the switch of the electrical installation. When the device is dirty, clean it with a clean dry cloth. Do not use liquid cleaning products such as benzene, thinner or flammable products. Never use paint thinners, solvents, cleaning products or cleaning pads impregnated with chemicals. MEIRI is not responsible for damages caused by improper use of the device or by changes made by the user and cannot cover data loss or destruction.


#### WARRANTY

Measuring devices are guaranteed 1 year by MEIRI, parts and labor, return to factory, except special provisions. Exchanges or repairs under guarantee cannot extend the term. In order to apply the warranty, the user must contact the MEIRI distributor who sold the device. No compensation is owed in case of stopping of the unit for repair under warranty. The warranty will not work in the following cases:


If the unit has been started on a voltage other than indicated on the nameplate. If the delivered equipment is misused, abused or changed. If the user causes damage through negligence, inadequate maintenance, lack of experience or use of harmful products. Warranty repairs are performed in our laboratories. The unit must be returned in packing ensuring its safety during transport. The user is responsible for shipping and packaging for the return of the unit at the factory. MEIRI or its distributor cover the freight and packing charges when returning the repaired device, but only in continental France.

## Front and rear panels of the 2657

Front panel



Rear panel



1. LCD DISPLAY (lines 16 characters)
2. Range lamps ( Min / OK / Max )
3. RESET and ESCAPE key
4. MENU key
5. TRACK-PEAK key / DOWN scroll
6. ZERO key / UP scroll
7. RS 232C connection
8. Strain gauge input (optional)
9. Fuse holder
10. Mains supply 85 to 264 Vac – 50/60 Hz
11. USB 2 connection
12. Input / Output connections  
O ← Range contacts output  
I → Remote Print, Tare & Zero inputs
13. Electronic torque sensor and quadrature encoder input (optional)
14. Mains On/Off switch

## Set up of the 2657

Press and release the  or  keys to choose the desired menu.

Use the  or  keys to modify the settings of the chosen menu.

### Menus of the 2657 version 1.1

MEIRI 2657 Ver : 1.1a	<b>Welcome menu at power up. Name of the instrument and firmware version.</b>
PASSWORD 0000	<b>An access code is needed to enter the menus. The access code for the 2657 is 0314. Use the scroll keys to input this value.</b>
LANGUAGE ENGLISH	<b>French, English, German, Spanish... 2 languages as standard, 6 others optional.</b>
MEASURING UNIT N.m	<b>32 units listed. N.m Ncm m.daN cm.daN cm.Kgf Lbf.in ...</b>
FULL SCALE 5.000 N.m	<b>Adjustable range from 0.1000 up to 9999. This value is used to scale and display the measured real physical magnitude.</b>
SENSITIVITY 2.000 mV/V	<b>For strain gauges (A) from 0.5 up to 2.5 mV/V For electronic sensors (B) from 2 up to 10V Analogue output <math>\pm 10V</math> for the chosen sensitivity</b>
REAL : + 00.26 TARA : + 00.00	<b>Use the  key to set point zero (displays zero-software compensated) Use the  key to clear the software offset (displays the real offset of the transducer)</b>
TYPE OF MEASURE PEAK +/-ANGLE	<b>Peak+, Peak-, Peak+ and angle, Peak- and angle.</b>
MODE OF MEASURE STANDARD	<b>Standard: the measure starts when the signal level is greater than the trigger value for at least the trigger time. Fast: the start of the measure is not conditioned by the trigger level and trigger time.</b>

FILTRE 500 Hz	Software averaging filter from 125Hz up to 10KHz.
TRIGGER TIME 0.007 s	Used in standard peak mode. The signal must be greater than the trigger level for at least this time in order to start the measure. Range 0.001 - 1.000 seconds
TRIGGER 0.500 N.m	Used in standard peak mode. The signal must be greater than this level for at least the trigger time in order to start the measure.
RESET TYPE AUTOMATIC	<b>Manual:</b> By pressing the RESET key on the front panel or by the remote RESET input trough the rear panel's I/O connector. <b>Automatic:</b> when the signal level re-drops below the trigger's. <b>Client:</b> Only the remote RESET is enabled with HOLD function.. Display is maintained until the input is released.
ENCODEUR 360 puls/tour	Access to this menu is enabled only if peak/angle mode is chosen. Range: 360 to 50000. (Puls/shaft)
10V OUT FOR 0360°	Defines the scale of the angle analogue output. (Degrees to have 10V analogue output, range: from 360° up to 50000°)
START ANGLE 0.000 N.m	The start of angle measuring is conditioned by the torque value given here. The condition is bypassed if the entered value is 0. (In this case the start of angle measuring is the same as torques.
STOP ANGLE 0.000 N.m	The end of angle measuring is conditioned by the torque value given here. The condition is bypassed if the entered value is 0. (In this case the end of angle measuring is the same as torque's.
LIMITS ON MEASURE AND ANGLE	Monitoring of the ranges can be set to measure, angle or both

MEASURE LOW LIM.  
+2.000 Nm

**Adjust in this menu the measure's low threshold value.**

MEASURE HIGH LI..  
+3.000 Nm

**Adjust in this menu the measure's high threshold value.**

**Note :** You can enter here positive or negative values as well. To avoid debouncing hysteresis is used. Its value depends on the decimal digits chosen to display (see menu DECIMAL DIGITS). The less the displayed decimal digits the greater the hysteresis. (See table of hysteresis values)

ANGLE LOW LIMIT  
0050°

**Adjust in this menu the angle's low threshold value**

ANGLE HIGH LIMIT  
0055°

**Adjust in this menu the measure's high threshold value.**

LIMIT TESTS  
REAL TIME

**In case of peak measuring the range relays and range lamps can be activated in real time or at the end of measure.**

INITIALITION  
PEAK

**The instrument will start measuring in the mode defined here. (After a power up and/or after the set-up procedure).**

While running it is possible to toggle the track/peak mode by simply pressing the  key.

FRONT ZERO P.B  
ENABLED

**By pressing the ZERO key while running the instrument will set the displayed values to zero. (Relative offset on the measure and resets the angle/position registers. This function key can be enabled/disabled in this menu**

DECIMAL DIGITS  
50.000

**Adjust the number of the displayed decimal digits from 0 to max. The max value depends on the chosen full-scale value of the measure.**

## CALIBRATION

**Calibration mode (advanced users only)**



**1st line: Full scale and sensitivity.**

**2nd line: Measured value.**

By pressing the up/down arrow keys the sensitivity is fine adjusted, thus the measured value will also change. Adjust the sensitivity until the measured value shows the calibre's value. During the calibration procedure make sure that the sensor's zero is correctly adjusted. The newly adjusted sensitivity should be saved (SAVE menu), for a proper functioning after a power off. /on cycle.

RS232 PARAMETERS  
9600, NON, 8

**RS 232C communication parameters set-up  
(32 possible combinations) from 2400 to 19200 bauds  
Displayed format: Baud rate, parity, 7/8 bits data (+1 STOP bit)**

DATE  
26-05-2007

**Date display and settings. Use the up/down arrow buttons to adjust the correct date: Displayed format: day-month-year**

TIME  
10 : 59 : 20

**Time display and settings. Use the up/down arrow buttons to adjust the correct time: Displayed**

STATISTIC MODE  
AUTOMATIC

**Three possibilities for the statistic computations.  
« Manual / Automatic / Disabled ».**

### **MANUAL STATISTICS :**

Static computations are done when requested by the user and the results are displayed on the screen.

### **AUTOMATIC STATISTICS :**

Statistic computations are done after the pre-programmed sampling numbers is reached. (See later Menu « AMOUNT values »)

### **DISABLED STATISTICS:**

Statistic computations are disabled. The acquired measures are only saved.

If this option is chosen the Menu+ will jump over all other menus relatives to the statistics parameters till « READ MEMORY »...



IMPRIME MEMOIRE  
APPUYEZ SUR ^

**Prints the records trough the RS232C port and if statistics are enabled, the statistics results as well.**

RESET MEMOIRE  
APPUYEZ SUR ^

**Clears all records.**  
**Note: The configuration parameters (sensitivity, measure) will not be erased.**

SAUVEGARDE  
APPUYEZ SUR ^

Save all the set-up parameters.  
**Warning: The changed set-up parameters will be lost if power is switched off prior to a save.**

## Display in mode « RUN » (after pressing the escape key)

In case of TRACK mode

```
+ 999.9 ft.lbs
```

```
>
```

1st line measure; unit of measure; alarms

In case of PEAK mode

```
+ 999.9 ft.lbs
```

```
>
```

```
9.999sec 500H
```

1st line measure; unit of measure; alarm

2nd line elapsed time since the START of measure in seconds; N° of the measure; H (if fast mode selected)

In case of TRACK and ANGLE mode

```
+ 999.9 ft.lbs
```

```
>
```

```
+9999.9°
```

```
<
```

1st line measure; unit of measure; alarms of the measure

2nd line angle in degrees, alarms of the angle

In case of PEAK and angle mode

```
+ 999.9 ft.lbs
```

```
>
```

```
+9999.9° 500H
```

```
<
```

1st line measure; unit of measure; alarm

2nd line angle in degrees, N° of the measure; H (if fast mode selected),

Alarms of the angle

### **PRINT examples** (not relevant values)

#### **In case of TRACK mode:**

```
+00.021;N.m;<;+0122.6;d;=
```

```
+00.021;N.m;<;-0055.8;d;<
```

```
+00.021;N.m;<;-0071.8;d;<
```

#### **In case of PEAK mode :**

```
2007-02-14;17:22:01;Nr;005;+001.51;cm.daN;<;0.100s;+0010.1;d;
```

```
2007-02-14;17:22:01;Nr;006;+001.49;cm.daN;<;0.116s;+0012.5;d;
```

```
2007-02-14;17:22:01;Nr;007;+001.44;cm.daN;<;0.090s;+0018.9;d;
```

#### **In case of PEAK mode and automatic statistics:**

```
2007-06-11;15:09:05;Nr;003;+00.0314;N.m;<;1.361s;+0000.0;d;<
```

```
2007-06-11;15:09:06;Nr;004;+00.0314;N.m;<;1.485s;+0000.0;d;<
```

```
2007-06-11;15:09:09;Nr;005;+00.0314;N.m;<;2.126s;+0000.0;d;<
```

```
.....;MIN.VALUE = 0.0314
```

```
.....;MAX.VALUE = 0.0784
```

```
.....; AVERAGE VALUE = 0.0408
```

```
.....;STD.DEVIATION = 0.021018
```

```
.....;CAM = 001.98
```

```
.....;CPK = 013.22
```

## ALARMS TABLE

### ALARMS STATE

**Note: the LEDS and RELAYS are associated; if the right red LED is on, the max relay is activated. If the left red LED is on, the min relay is activated. If the green LED is on both the min. and the max. Relays are deactivated.**

High level	RIGHT LED >
OK	MIDDLE LED =
Low level	LEFT LED <

### ALARM RELAYS STATES

	Contacts states	Low level	Ok	High level	In set-up mode	At power off
Low level Relay	Contact normally closed (pin 1-9)	Closed	Open	Open	Open	Closed
	Contact normally open (pin 2-9)	Open	Closed	Closed	Closed	Open
High level Relay	Contact normally closed (pin 11-3)	Open	Open	Closed	Open	Closed
	Contact normally open (pin 10-3)	Closed	Closed	Open	Closed	Open

Alarms on measure			Alarms on angle			Alarms on measure and angle		
Left LED MIN	Middle LED OK	Right LED MAX	Left LED MIN	Middle LED OK	Right LED MAX	Not ok Left LED	Ok Middle LED	Not ok Right LED
Measure low	Measure Ok	Measure High	Angle low	Angle ok	Angle high	Angle Not ok Low or High	Measure and angle ok	Measure not ok Low or High

**Note: The levels are in positive security. The relays are in alarm state if the power is off or in set-up mode.**

**Range levels hysteresis values.**


FULL SCALE	DECIMAL NUMBERS	HYSTERESIS
<b>0.XXXX</b>	<b>0.XXXX</b>	<b>0.0001</b>
	<b>0.XXX</b>	<b>0.001</b>
	<b>0.XX</b>	<b>0.01</b>
	<b>0.X</b>	<b>0.025</b>
<b>X.XXX</b>	<b>X.XXXX</b>	<b>0.0010</b>
	<b>X.XXX</b>	<b>0.001</b>
	<b>X.XX</b>	<b>0.01</b>
	<b>X.X</b>	<b>0.1</b>
	<b>X.</b>	<b>0.25</b>
<b>XX.XX</b>	<b>XX.XXX</b>	<b>0.010</b>
	<b>XX.XX</b>	<b>0.01</b>
	<b>XX.X</b>	<b>0.1</b>
	<b>XX.</b>	<b>0.25</b>
<b>XXX.X</b>	<b>XXX.XX</b>	<b>0.10</b>
	<b>XXX.X</b>	<b>0.1</b>
	<b>XXX.</b>	<b>1.</b>
<b>XXXX</b>	<b>XXXX.X</b>	<b>1.0</b>
	<b>XXXX.</b>	<b>1.</b>

## CONNECTORS PINOUT (REAR PANEL)

Mains :	Standard « Schaffner » connector
Sensors:	Amphenol 12 and 7 pins female connectors
Alarms, Reset and remote inputs	DB 15 male connector
RS232C	DB 9 female connector
USB	USB TYPE B connector

**REMARK:** The screening of the cables must be connected to the case of the connectors.

### *RS 232C connector pin out*

1	N. C.	
2	RX	
3	TX	
4	N.C.	
5	GND	
6	N.C.	
7	N.C.	
8	N.C.	
9	N.C.	


### ***DB15 male Connector***

<b>Contact normally closed min.</b>	<b>1</b>
<b>Contact normally open min.</b>	<b>2</b>
<b>Contact common max.</b>	<b>3</b>
<b>GROUND</b>	<b>4</b>
<b>Encoder analogue output ±10V</b>	<b>5</b>
<b>GROUND</b>	<b>6</b>
<b>PRINT</b>	<b>7</b>
<b>Not connected</b>	<b>8</b>


<b>Contact common min.</b>	<b>9</b>
<b>Contact normally open max.</b>	<b>10</b>
<b>Contact normally closed max.</b>	<b>11</b>
<b>+5V 10mA max !</b>	<b>12</b>
<b>Measure analogue output ±10V</b>	<b>13</b>
<b>RESET remote input</b>	<b>14</b>
<b>TARA remote input</b>	<b>15</b>

## INPUT/OUTPUT EQUIVALENT SCHEMATICS


### ANALOGUE OUTPUTS



### RESET, PRINT, TARA Inputs



### Relays contacts




## Cable connexions 7 and 12 pins 2657 (Some inputs might be optional)

Female 12-pins am phenol Brushless torque sensor with build in encoder	Socket B
+15V	H
Encoder phase B	C
-15V	J
Encoder Phase A	D
M+ for torque tension input (U)	G
GROUND	A et E
Case ground	L


Female 7-pins am phenol Strain gauge sensor	Socket A
A+ gauge	6
M- gauge	1
A- gauge	4
M+ gauge	2
GROUND	7
Set to GROUND to select this input	3
NOTE : If pin 3 left unconnected = dynamic torque sensor $\pm 5V$ (u) If pin 3 grounded = strain gauge sensor.	

SENSOR B



Cable **CONNECTOR**  
front view

SENSOR A



**SOCKET** at rear panel  
front view

Nota:

For ICP version Sensor A is replaced by a BNC socket

And sensor B and ANGLE menus is NOT USABLE.

## PC 2657 SOFTWARE INSTALLATION GUIDE

To get the software, register on our website :  
<http://celians.com/inscriptionST.html>

### Recommended configuration:

PC with USB2 port, minimum 800MHz processor, 20Mo free HD space, 128Mo of RAM.

Through the USB port on the 2657, is possible to remotely set-up the measuring system with a PC. The PC software supplied with the instrument allows a complete set-up and data logging directly into the PC. The acquisition frequency can be as high as 16 000 measures/seconds depending on the PC and it's operating system. There is no more need to install an acquisition board into the PC.

Automatic detection occurs when the 2657 is connected to the PC's USB port.

### WARNING :

**DO NOT CONNECT THE INSTRUMENT BEFORE HAVING INSTALLED THE SOFTWARE.**

### 1 - Installation for Windows 2000 and XP

- Run the CDM 2.02.04.exe from the folder « Install MEIRI 2657 » : \Drivers MEIRI 2657\Win 2000 & XP\.
- Run « setup.exe » from the root of « Install MEIRI 2657 ».  
Keep ***absolutely*** all default path options and finish the installation.
- Wait the end of installation before hit a key to finish the DOS windows
- Power up the instrument
- Connect the USB cable to the PC
- Windows will find a new hardware.
- Wait till WINDOWS finishes installing completely the different drivers, until the message « the new hardware is ready to be used ».
- Go to « Start » « Programs » « MEIRI 2657 » et run the program MEIRI 2657  
Or, another way, run « C:\MEIRI2657\MEIRI2657.exe. »

### 2 – Installation for Windows 98 and ME

- Run « Install.bat » from the root of « Install MEIRI 2657 ».  
Keep ***absolutely*** all default path options and finish the installation.
- Wait the end of installation before hit a key to finish the DOS windows
- Power up the instrument.
- Connect the USB cable to the PC
- Windows will detect a new hardware device and when asks for it's driver, browse to « CD installation ” :  
\Drivers MEIRI 2657\win98 & ME\.
- Go to « Start » « Programs » « MEIRI 2657 » et run the program MEIRI 2657  
Or, another way, run « C:\MEIRI 2657\MEIRI2657.exe. »

Note: For updating the newer versions of the software you have to uninstall the existing software by running « **Install.bat** ».


Then install the newer version by running « **Install.bat** » again.

## “2657” SOFTWARE LAYOUT

Upon running the software the below picture is shown.

The program detects automatically all connected channels.

The green light indicator (left high corner) will be on when the instrument is connected to the PC.



## SIGNAL CONDITIONER CONFIGURATION

On the menu bar choose « configuration »

A new window will show up proper to the selected channel.

The configuration values are limited. If an out of range value is entered it will be automatically set to the maximum/minimum allowed value.

**Sensor configuration**

Sensor value: **+0.0 g** (Real time measure display)

Type: Jauge

Full scale: 50.00 g

Sensitivity: 0.500 V

Unit: g

Filter: ...

Time: 0.001 s

Trigger: 1.00 g

Decimal: 1

Mode: Standard

Reset: Manual

Buttons: Zero (Tara Sensor zero setpoint), Cancel zero, Close

Callout: Sensor configuration values

**Angle configuration**

Angle value: **+0.0 °** (Angle measure real-time display)

Pulse / rev: 360

10V out for: 360 °

Start angle: 0.00 g

Stop angle: 0.00 g

Button: RESET encoder (Sets to zero the angle measure)

Callout: Angle encoder configuration value

**Threshold monitoring**

Limits on: sensor

Alarm: Real time

Min sensor threshold: -0.20 g

Max sensor threshold: 30.00 g

Min angle threshold: 0 °

Max angle threshold: 0 °

Callout: Alarm level settings

**Tracability**

Mode: Blocked

Nominal sensor: 10.00 g

P tolerance: 0.50 g

M tolerance: 0.75 g

Number of sample: 5

Analysis

Min: \_\_\_\_\_ g

Max: \_\_\_\_\_ g

Average: \_\_\_\_\_ g

Standard deviation: \_\_\_\_\_

CAM: \_\_\_\_\_

CPK: \_\_\_\_\_

Close

Statistic parameters settings

Statistical results

Upload the measures log file to from the 2657 to this window

Clears the content of this window

**Memory**

Transfer      Reset

```

2008-07-01:11:48:19.Nr:072+030.1.g>=0.005s;.....
2008-07-01:11:48:19.Nr:073+032.2.g>=0.002s;.....
2008-07-01:11:48:21.Nr:074+030.4.g>=0.014s;.....
2008-07-01:11:48:22.Nr:075+001.7.g>=0.009s;.....
2008-07-01:11:48:23.Nr:076+001.7.g>=0.030s;.....
2008-07-01:11:48:24.Nr:077+001.8.g>=0.006s;.....
2008-07-01:11:48:25.Nr:078+001.7.g>=0.008s;.....
2008-07-01:11:48:26.Nr:079+001.6.g>=0.005s;.....
2008-07-01:11:48:27.Nr:080+001.5.g>=0.007s;.....
2008-07-01:11:48:28.Nr:081+001.7.g>=0.010s;.....
2008-07-01:11:48:29.Nr:082+001.6.g>=0.017s;.....
2008-07-01:11:48:30.Nr:083+001.6.g>=0.018s;.....
2008-07-01:11:48:31.Nr:084+001.8.g>=0.015s;.....
2008-07-01:11:48:32.Nr:085+001.7.g>=0.007s;.....
2008-07-01:11:48:32.Nr:086+000.2.g>=0.006s;.....
2008-07-01:11:48:33.Nr:087+001.7.g>=0.009s;.....
2008-07-01:11:48:34.Nr:088+001.4.g>=0.007s;.....
2008-07-01:11:48:35.Nr:089+001.7.g>=0.009s;.....
2008-07-01:11:48:41.Nr:090+001.8.g>=0.132s;.....
2008-07-01:11:48:42.Nr:091+001.5.g>=0.017s;.....
2008-07-01:11:48:44.Nr:092+001.7.g>=0.026s;.....
2008-07-01:11:48:45.Nr:093+001.5.g>=0.009s;.....
2008-07-01:11:48:46.Nr:094+001.6.g>=0.010s;.....
2008-07-01:11:48:47.Nr:095+001.6.g>=0.009s;.....
2008-07-01:11:48:48.Nr:096+001.6.g>=0.018s;.....
2008-07-01:11:48:50.Nr:097+001.6.g>=0.025s;.....
2008-07-01:11:48:51.Nr:098+001.6.g>=0.012s;.....
2008-07-01:11:48:53.Nr:099+001.6.g>=0.026s;.....
2008-07-01:11:48:55.Nr:100+001.6.g>=0.025s;.....
2008-07-01:11:48:56.Nr:101+001.6.g>=0.018s;.....
2008-07-01:11:48:58.Nr:102+001.6.g>=0.024s;.....
2008-07-01:11:48:59.Nr:103+001.7.g>=0.006s;.....
2008-07-01:11:49:00.Nr:104+001.6.g>=0.009s;.....
2008-07-01:11:49:07.Nr:105+001.7.g>=0.006s;.....
2008-07-01:11:49:08.Nr:106+001.7.g>=0.007s;.....
2008-07-01:11:49:09.Nr:107+001.8.g>=0.006s;.....
2008-07-01:11:49:10.Nr:108+001.6.g>=0.010s;.....

```

Save

Close

Uploaded measures file from the 2657's memory

Save the content of this window into a file

**Box configuration**

**Box name**

enter name for this 2657

Change box name

**Date and hour**

Date: 01 / 07 / 2008

Hour: 16 : Minute: 59 : Second: 12

Change date and hour

Zero button: Blocked

Init: Peak

Close

Change the name of this instrument. It will be saved and recognized as named at the next start up.


Date and time settings into the real time keeper of the instrument.

Enables/disables the instrument's zero key function

Defines the instrument mode of measure after an escape or at start-up.

## VIEWING REAL-TIME WAVEFORMS

The “Graphs” button from the main windows allows to open the viewing real-time waveforms windows :



## Data acquisition on the PC


### DATA ACQUISITION ON THE PC

#### « Acquisition ON »

The green light will be on once the acquisition has started.

#### « Acquisition frequency »

With this button you can select frequency-based values for high-speed data acquisition or time based values in seconds for low speed data acquisition. The system's maximum acquisition speed is 16 000 samples per seconds and the minimum speed is 1 measure each 16000 seconds which is one measure cca. each 4h26 .




#### « Start of acquisition »

This button defines the data acquisition starting mode.

**Manual Mode:** Instant start of the acquisition once the «Start acquisition» button is pressed.

**Timer Mode:** by setting a real time value (hours, minutes, seconds). This time is based upon the Windows O.S. real time clock.

**Trigger Mode:** by setting a trigger level, an under/over condition (> or <) and a memory buffer size. It is the same for the pre and post trigger.



#### « End of acquisition »


Several modes of Stop acquisition are possible.

**Manual mode:** Instant stop of the acquisition by pressing this button.

**Real time mode:** Stop at a given time (hours, minutes, seconds) This time is based upon the « Windows » operating system real time.

**Time interval mode:** Acquisition stops after the pre-programmed time by the user has elapsed (hour, minutes, seconds).

**Trigger Mode:** by setting a trigger level, an under/over condition (> or <) and a memory buffer size. It is the same for the pre and post trigger.



### CONFIGURING THE TRIGGERS

« **Memory buffers sizes** »: pre and post trigger duration size in seconds.

#### « Acquisition type »:

**Mono trigger:** starts the acquisition only once


**Multi trigger:** always starts the acquisitions when the required conditions are fulfilled, and will automatically make a new file with an auto-incrementing name (e.g.: Test1.csv, Test2.csv, ....)

**Start condition:** starts the acquisition if the signal is > or < than the entered value.

**Start Value:** Reference triggering value for start acquisition.

**Stop condition:** stops the acquisition if the trigger level is > or < than the value specified below

**Stop value:** Reference triggering value for stop acquisition.




## Data acquisition files

### **Directory and file base name:**

At the first use, the system requests the path and file name you want to give to your export files. Go to "File" menu then "Export", browse to the directory you wish to store the export files and specify a base file name. This name will be assigned to your files and auto-incremented for successive acquisitions

Note : For files from the acquisition the extension is .csv compatible with Microsoft Excel. For files "print screen" from the "Graphics" windows, the file is named imageXXX.bmp, and increments.



The **Separator type** has to be the same as « Microsoft Excel » uses. From the menu bar open « configure the swap file » window and choose the right « ; » or « , » **separator** used by your « Microsoft Excel » version.

Once the data acquisition is finished go to the previously defined directory where the data acquisition files are stored and double click on one of them. Microsoft Excel will open and within you can exploit all your results, trace your chart, compute average values, etc. ...

**Note : maximum 1 048 576 lines can be used in Microsoft Excel 2007.**

When you open with Excel a csv file form an acquisition, the below table will be shown:

Temps (s)	Measure (Kgf)	Angle (°)	Depassement	
			30/09/2011	15:03:07
0	0.0372	-49		
0.00006	0.0372	-49		
0.00013	0.032	-49		
0.00019	0.036	-49		
0.00025	0.0363	-49		
0.00031	0.0339	-49		
0.00038	0.036	-49		

## TECHNICAL CHARACTERISTICS

<i>CONDITIONER AMPLIFIERS FOR STRAIN GAUGE SENSORS</i>		
<b>Sensor Excitation tension</b>	10*	V dc
<b>Sensor minimum Impedance</b>	350*	$\Omega$
<b>Sensitivity range</b>	0.5 to 2.500	mV/V
<b>Full scale</b>	0.1000 to 999.9	
<b>Linearity</b>	0.05	%
<b>Thermal drift</b>	< 1	$\mu\text{V}/^\circ\text{C}$
<b>Bandwidth</b>	14000	Hz
* Other values possible if requested		

<i>CONDITIONER AMPLIFIERS FOR ICP<sup>®</sup> SENSORS</i>		
<b>Sensor Excitation constant current</b>	4 to 10	mA
<b>Voltage excitation</b>	24	V
<b>Sensitivity range</b>	0.5 to 2.500	V
<b>Full scale</b>	0.1000 to 999.9	
<b>Linearity</b>	0.1	%
<b>Thermal drift</b>	10	$\mu\text{V}/^\circ\text{C}$ typ
<b>Bandwidth</b>	20000	Hz
* Other values possible if requested		

<i>CONDITIONER AMPLIFIER FOR <math>\pm 5\text{V}</math> or <math>\pm 10\text{V}</math> TENSION OUTPUT SENSORS</i>		
<b>Sensor Excitation tension</b>	$\pm 15$	V dc
<b>Sensitivity range</b>	2 to 10.000	V
<b>Full scale</b>	0.1000 to 999.9	
<b>Linearity</b>	0.05	%
<b>Thermal drift</b>	< 1	$\mu\text{V}/^\circ\text{C}$
<b>Bandwidth</b>	14000	Hz
* Other values possible if requested		

<i>DIGITAL EQUIPEMENT</i>		
<b>Micro controller</b>	RISC	
<b>Oscillator</b>	40	MHz
<b>Acquisition frequency</b>	100 KHz maxi	Menu defined
<b>Analogue/Digital converter</b>	2 x 16 Bits	Input converter
<b>Digital/Analogue converter</b>	2 x 12 Bits	Output converter
<b>Input resolution for +/- F.S.</b>	+/- 32768	Points

<i>ANA LOG OUTPUTS</i>		
<b>Measure and angle analogue outputs</b>	2 x $\pm 10\text{V}$	Bandwidth : 500 Hz at -3dB



<i>REMOTE INPUTS (REAR PANEL)</i>		
<b>RESET</b>	By potential free contact or TTL level	ACTIVE: closed or at 0
<b>PRINT</b>	By potential free contact or TTL level	ACTIVE: closed or at 0
<b>TARA</b>	By potential free contact or TTL level	ACTIVE: closed or at 0

<i>RS232C SERIAL COMMUNICATION</i>		
<b>Direction</b>	Transmission	
<b>Speed</b>	2400, 4800, 9600, 19200	Bauds
<b>Data bits</b>	7, 8 (1 STOP bit)	
<b>Parity</b>	No parity, Even, Odd	

<i>RS232 CHARACTERISTICS</i>		
<b>Delay time between Print request and start of the print frame</b>	3 to 50 ms	Value range
<b>Print frame length at 2400, 4800, 9600, 19200 bauds</b>	170, 80, 20, 11	ms
<b>Print request speed at 2400, 4800, 9600, 19200 bauds</b>	9, 20, 26 Impressions / seconds	
AN impulse shorter than 30 ms will trigger the print of one line on the RS232C port If this input is maintained at zero level (GROUND) print will be continuous up to 20 measures/seconds.		
<b>Available only if the remote input (DB15 pin 7) at the rear panel is enabled.</b>		

<i>RANGE RELAYS OUTPUTS</i>		
<b>CONTACTS</b>	Still / work 0,5A maxi	220V maximum
<b>Hysteretic</b>	With maximum decimal numbers	10 points
	With other displayed modes Ex: display 1.00 hysteresis = $\pm 0.01$	$\pm 1$ displayed Point

Given values are indicatives. The constructor reserves the right to change them without prior notice.

<i>MAINS POWER</i>		
<b>Tension</b>	85 to 264Vac	50-60Hz
<b>Fuse</b>	1 A on the rear panel	Type 5x20 mm
<b>Mains filter</b>	Schaffner	
<b>Power</b>	15 (typical)	W
<b>Maximum power consumption</b>	20	W

<i>TEMPERATURE</i>		
<b>In-use Temperature</b>	0 to 50	°C
<b>Stocking Temperature</b>	-10 to + 70	°C

END OF DOCUMENT